

# CROCHET BLINDSTITCH / CROCHET - COLTELLI BROTHER

## CROCHET BLINDSTITCH



36C22-1  
COLUMBIA



36-16  
LEWIS cl. 150  
CONSEW cl. 221



A3239  
US2200  
22 (# 2200)  
US-Rim 1099BL

MAIER  
A3239M



A3240  
V220111  
UNITAS  
cl. 221; 241;  
251



A3241  
223111  
(# V252111)  
UNITAS  
cl. 232; 242;  
252; 342; 352



A3242  
401073  
(# 400041)  
SINGER  
DEARBORN



A3243/187028  
VLA 48-4  
(# 187028)  
STROBEL



A3243  
187053  
STROBEL



80413  
YAMATO  
cl. CM263; 268



110121-001  
BROTHER  
cl. B931; 932



11837 (# T830)  
TREASURE  
cl. BS800; 808; 810;



830; 860  
MAUSER  
cl. 68-16211; 68-17321



## CROCHET - COLTELLI BROTHER

FD4-B 270 Series  
B 2700 Series



S 08913-001



S 08934-001



S 09075-001



S 09080-001  
(CT)



S 09094-001  
(CT)



S 09093-001  
(CT)



S 09101-001



S 12842-001



S 12865-001

B 281

altri ricambi BROTHER, nelle seguenti sezioni:  
ricambi Brother da pag. 179 ~ placche e griffe Brother a pag. 152

# CROCHET - COLTELLI BROTHER

**BAS 310, 311  
BAS 430, 433**



S 102 05-001




S 10210-001

**BAS 320, 322**



S 02 375-001



S 02374-001



**LK3-B 430, B 433, B 434, B 441  
KE-430C-436C  
KM-4300**



152905-00



152901-001




154176-001



152906-001

**DB2 - B 716**



154575-001



154568-001

**B 737, B 738**




S 02 645-001



S 02 637-001

**DBZ-B 755**



142061-001



142058-001

**B 832, B 833, B 837  
B 600  
BAS 620**





159365-001



153019-001  
= Eagle 21-4001

**B 814, B 815, B 816,  
= Singer KI. 71**



141543-001



141541-001

coltelli asole per: **NECCHI - SINGER - DURKOPP - BROTHER - JUKI**  
**A2350** normali **A2352** diritti per seta  
**A2350M** versione **MAIER** **A2352M** versione **MAIER**  
 (il modello diritto è compatibile **PFAFF**)


misure prodotte: da mm. 3,2 a mm. 38

# CROCHET - COLTELLI BROTHER

## B842 - B875



S 07526-001



S 07526-201



S 07527-001

## B 913; B 915; B 917



115069-001



S 03536-001



S 03627-001

## B 926-6A



S 03629-001



148869-001



148870-001



148871-001



110121-001

## serie B500 - B600 - B900



140567-001



CT 140567-001



140242-001



148815-001



148198-001



144074-001



1250014-299



118527-001



144077-001



CT 144077-001



112376-001



112436-001  
155193-001




112436-001 BAK  
Ceramic



CT 112436-001

# CROCHET - COLTELLI BROTHER



**EF 4 -V 41, -V 51, -V 71, -V 72, -V 81, -V 82**  
**MA 4 -V 61, -V 91, -V 92 -N 11, -N 21, -N 31**

