

# COLTELLI EAGLE / CROCHET – COLTELLI JUKI

## COLTELLI EAGLE



**21-5602**  
KL. 1010/1020:  
520087  
KL. 2001:  
6502114  
PL-2-13



**21-3002**  
21-4012  
520018  
PL-2-30  
(CT)



**21-4587**  
512035



**21-3003**  
650704  
527013  
PL-9-9  
HSS



**15487**  
21-3003-01  
6507044  
Ceramic




**21-4001**  
520002  
KL. 1005F/1005FZ



**21-3004**  
512018  
KL. 1002



MS 3-017 L




MS 3-017 R

MUSASHI-21

## CROCHET-COLTELLI JUKI

**LBH 761-763, 771-773, 781-784, LBH 793, LBH 1700**  
= Singer Kl. 71



B 2408-771-000



B 2406-771-0A0



B 2408-761-000



B 2406-761-0A0

**HSS =**  
**High speed steel**

A2350 normale  
A2350M MAIER

A2352 diritto  
A2352M MAIER

misure da mm.3,2 a mm.38




B 4108-352-00 D  
CT



B 2011-357-



B 2520-352-000




B 2421-210-AA0

**MO 352, 357**



B 4122-352-00 A



B 2521-352-000

**AMS 210, 212**



B2424-210-A00



B 2424-210-000



B 2421-205-0A0