

CROCHET BLINDSTITCH / CROCHET - COLTELLI BROTHER

CROCHET BLINDSTITCH



36C22-1
COLUMBIA



36-16
LEWIS cl. 150
CONSEW cl. 221



A3239
US2200
22 (# 2200)
US-Rim 1099BL

MAIER
A3239M



A3240
V220111
UNITAS
cl. 221; 241;
251



A3241
223111
(# V252111)
UNITAS
cl. 232; 242;
252; 342; 352



A3242
401073
(# 400041)
SINGER
DEARBORN



A3243/187028
VLA 48-4
(# 187028)
STROBEL



A3243
187053
STROBEL



80413
YAMATO
cl. CM263; 268



110121-001
BROTHER
cl. B931; 932



11837 (# T830)
TREASURE
cl. BS800; 808; 810;



830; 860
MAUSER
cl. 68-16211; 68-17321



CROCHET - COLTELLI BROTHER

FD4-B 270 Series
B 2700 Series



S 08913-001



S 08934-001



S 09075-001



S 09080-001
(CT)



S 09094-001
(CT)



S 09093-001
(CT)



S 09101-001



S 12842-001



S 12865-001

B 281

altri ricambi BROTHER, nelle seguenti sezioni:
ricambi Brother da pag. 179 ~ placche e griffe Brother a pag. 152